

COMPLETE CITY WATER KIT

Sampling Instructions

- 1 Metals** (1 250 ml plastic bottle)
 - Fill to the neck of the bottle.
- 2 Minerals** (1 500 ml plastic bottle)
 - Fill to the neck of the bottle.
- 3 Water Quality Properties** (1 250 ml plastic bottle)
 - Fill to the neck of the bottle.
- 4 Radon** (2 30 ml glass vials)
 - Run cold water for 15-20 minutes at a moderate rate so that there is little or no splashing.
 - Reduce water flow, and put a clean, deep bowl or pan under the tap until it's full and overflowing.
 - Open the two glass vials and place both the caps and vials into the bowl or pan.
 - With the water still running, lift the bowl/pan to completely submerge the head of the faucet (nozzle), to minimize agitation and subsequent loss of radon.

(Instructions continued on back)