

COMPLETE WELL WATER KIT

Sampling Instructions

- 1 Bacteria** (1 120 ml plastic bottle, with sodium thiosulfate)
 - Fill the bottle to the maximum fill line.
 - Do not touch the inside of the cap or bottle.
- 2 Metals** (1 250 ml plastic bottle)
 - Fill to the neck of the bottle.
- 3 Minerals** (1 500 ml plastic bottle)
 - Fill to the neck of the bottle.
- 4 Water Quality Properties** (1 250 ml plastic bottle)
 - Fill to the neck of the bottle.
- 5 PFAS** (2 250 ml plastic bottles, with TRIZMA)
 - Fill the two plastic bottles to the neck of each bottle.
 - Cap each bottle and turn them upside down five times to mix in the preservatives.
- 6 Radon** (2 30 ml glass vials)
 - Run cold water for 15-20 minutes at a moderate rate so that there is little or no splashing.
 - Reduce water flow, and put a clean, deep bowl or pan under the tap until it's full and overflowing.

(Instructions continued on back)